


FADS Assembly

601-000-110



Airofog USA
15074 Aviation Loop Drive
Brooksville, FL 34604
USA

+1-352-593-5152
airofog@airofogusa.com
www.airofogusa.com

FADS Parts List

Pos.	Part no.	Description
1	601-001-400	Can clamp cpl.
2	601-001-410	Wing lock
3	601-001-420	Can clamp
5	601-002-410	Valve seat
6	505-009-060	Viton o-ring
7	601-002-430	Valve seat g1/8"
9	601-002-450	Can clamp assembly
10	505-002-020	Gasket
11	601-003-000	Ball valve g1/8"
25	604-025-100	Hose replacement kit (26/2x2, 26/3x2, 27)
26	601-004-010	Hose adapter assembly
26/1	601-004-011	Adapter g1/8"
26/2	601-004-012	Cutting ring
26/3	601-004-013	Retaining nut
27	601-004-130	Coiled hose; blue
28	601-004-040	Hose holder spring
28/1	603-004-040	Hose holder spring
29	601-007-000	Flexi-valve assembly (30-38)
30	601-007-010	Valve handle

Service kits

601-023-010	Valve seat service kit (6, 10x2)
601-023-200	Flexi-valve service kit (34, 35x2, 39x3)

Pos.	Part no.	Description
31	601-007-020	Valve body
32	505-003-014	Spring
33	601-007-040	Seat
34	601-007-060	Viton o-ring
35	935-041-000	Viton o-ring
36	601-007-070	Seat sleeve
37	601-007-080	Valve cup
38	601-007-090	Trigger
39	601-007-100	Viton o-ring
40	601-008-010	Spiral wand extension
41	601-009-000	Aerosol nozzle set (41/1, 41/3, 41/4)
41/1	601-009-030	White aerosol nozzle
41/3	601-009-050	Blue aerosol nozzle
41/4	601-009-070	Red aerosol nozzle
42	601-010-000	C&C extension set (42/1, 42/1, 42/3, 42/4, 42/5)
42/1	601-010-012	C&C extension 5" (optional)
42/2	601-010-020	C&C extension 8" (optional)
42/3	601-010-030	C&C extension 12" (optional)
42/4	601-010-040	C&C extension 15" (optional)
42/5	601-010-050	C&C extension 20" (optional)
45	601-020-080	Airofog carrying pouch



Airofog USA
15074 Aviation Loop Drive
Brooksville, FL 34604
USA

+1-352-593-5152
airofog@airofogusa.com
www.airofogusa.com