


TOMAHAWK


PARTS CATALOG BACKPACK SPRAYER TPS25





NO.	Part NO.	Part Name	Qty.	NO.	Part NO.	Part Name	Qty.
1	3WZ-6.5.2-1	LID	1	18	3WZ-4C.3	FREL THROTTLE	1
2	3WZ-4.7.1-3	LID	1	19	3WZ-6-2	PLASTIC NUT	2
3	3WZ-4.7.1-4	LID	1	20	3WZ-6.1	RUBBER MOUNT	2
4	3WF-8.1-1	SEALING WASHER	1	21	3WZ-6.9	CONNECT PLATE	1
5	3WZ-4.7.2	FILTER ASSM	1	22	GB/T9074.13 M5×20	SCREW ASSEM 5×20	2
6	3WZ-6.5.1	CHEMICAL TANK	1	23	3WZ-6-3	SUPPORT MOUNT	1
7	1E34F-XSHJ.1	SWITH	2	24	BG415.4	RUBBER MOUNT	1
8	3WF-28.7	BANDS ASSM	1	25	3WZ-6C-6	WASHER	1
9	3WF-3A.1-2	SEALING WASHER	1	26	3WZ-6-5	RIGHT SUPPORT	1
10	3WZ-6.5-1	LID	1	27	3WZ-6-9	LEFT SUPPORT	1
11	GB/T818 M6×12	SCREW	4	28	3WZ-4.14	LONG NOZZLE	1
12	GB/T96 6	WASHER 6	9	29	3WZ-4.13	STAIGHT SPRAYING TUBE	1
13	3WZ-6-2	FRAME	1	30	3WZ-4-10	SEAL RING	4
14	3WF-2.6B-2	PLASTIC CLICK	4	31	3WZ-4.12	VALVE	1
15	3WZ-6.2	BACK DACK ASSM	1	32	3WZ-4.11	HANDLE	1
16	GB/T6177.1 M6	NUT M6	6	33	3WZ-6.6.1	RUBBER TUBE ASSY	1
17	GB/T29.2 M6×20	BOLT M6×20	3	34	3WZ-6B-ST	TEE	1






NO.	Part NO.	Part Name	Qty.
8	768-8	SCREW	1
11	GB96 φ6	WASHER	1
25	GB889.1 M6	TUBE	1
47	768-47	BOX	1
48	768-48	PISTON	1
50	768-50	GEAR SHAFT	1
51	768-51	BEARING	1
52	768-52	O-RING	4
53	768-53	WASHER	1
54	768-54	WASHER	1
55	768-55	LID	1
56	768-56	CLUTCH DRUM COVER	1
57	768-57	BEARING	1
58	768-58	BEARING	1
60	768-60	GEAR	1
61	768-61	BEARING	1
62	768-62	O-RING	1
63	768-63	LID	1
64-1	768-64	O-RING	1
65	768-65	SCREW	4
66	768-66	O-RING	1
67	768-67	RULE	1
68	768-68	O-RING	1
69	768-69	SCREW	1
70	768-70	SEAL	2
71	768-71	O-RING	2
72	768-72	RING	2
73	768-73	SEAL	2
74	768-74	RING	2
75	768-75	SEAL	2
76	768-76	SEAL	2
77	768-77	SEAT	2
78	768-78	CYLINDER	2
79+80	768-79+80	RING	2
81	768-81	PISTON	4
82	768-82	DISCHARGE METAL	1
83	768-83	CLIP	2
85	768-85	OVERFLOW METAL	1
86	768-86	VALVE SEAT	1
88	768-88	BALL	1
89	768-89	CONE	1
90	768-90	SPRING	1

NO.	Part NO.	Part Name	Qty.
92	768-92	SCREW	2
93	768-93	VALVE	1
94	768-94	NUT	1
95	768-95	SHAFT	1
96	768-96	WHEEL	1
98	768-98	SCREW	4
99	768-99	PLUNGER	1
100	768-100	TUBE	1
101	768-101	CYLINDER	1
102	768-102	OVERFLOW METAL	1
103	768-103	DISCHARGE METAL	1
104	768-104	TUBE	1
123	768-123	BOARD	2
56	GB/T276 6001/P5	BEARING	2
57	3WZ-4.9.1-3	GEAR SHAFT	1
58	3WZ-4.9.1-4	LID	1
59	GB/T889 M5	NUT M5	2
60	3WZ-4.9.2	CLUTCH DRUM COVER	1
61	3WZ-4.9-2	CLUTCH DRUM ASSM	1
62	GB/T9074.4 M5×12	SCREW ASSM M5×12	4





NO.	Part NO.	Part Name	Qty.
1	GB/T67	SCREW M5X12	1
2	1E36F.1-4	POPER REEL WASHER	1
3	1E36F.1-3	STARTER POPER REEL	1
4		ROPER (φ3.5X860)	1
5	1E36F.1-2	RECOIL SPRING	1
6	1E36F.1.1.1	RECOIL STARTER BODY	1
7	1E36F.1-1	STARTER HANDLE	1
8	1E36F.1-5	RING	1
9	GB/T9074.4	SCREW M4×16	3
10	GB/T97.1	WASHER 8	1
11	GB/T66170	NUT M8	1
12	1E46FP.4-2	START CLAW	1
13	1E36F.1.2-2	START SPRING	1
14	1E36F.1.2-1	START REEL	1
15	GB/T896	STOP RING 4	1
16	1E36F.2	OIL-SEAL	2
17	1E31F.8-2	CRANK CASE	1
18	GB/T276	BEARING 6201/P5	2
19	1E31F.4.3	CRANK SHAFT	1
20	GB/T1099	KEY 3X5X13	1
21	GB/T119	PIN B4×10	2
22	1E31F.8-1	CRANK CASE	2
23	1E31F.6-1	FLASH PAN	1
24	GB/T119	PIN B4×10	2
25	GB/T9074.4	SCREW M5X25	3
26		MAGNETO ROTOR COMP.	1
27	GB/T859	WASHER 8	1
28	GB/T97.1	WASHER 8	1
29	GB/T6170	NUT M8	1
30		IGNITION COIL COMP.	1
31	1E31F.3.1	CORD COMP.	1
32	GB/T9074.13	BOLT M5×20	4
33	1E34F.11	WASHER B	2
34	1E34F.10-1	SPRING	1
35	1E34F.10.1	EXPANDER	2
36	1E34F.13	WASHER	2
37	1E34F.12	SCREW PIN	2
38	1E31F.6-2	FAN COVER	1
39	GB/T9074.13	BOLT M5×16	2
40	1E40F-3A.9	CLIP	1
41	1E31F.4.1	BEARING	1
42	1E31F.4-3	RING	2
43	1E33F.1.2	PISTON	1
44	1E31F.4-2	PISTON PIN	1
45	1E31F.8-3	GASKET	1
46	1E33F.1-1	PISTON RING	2
47	1E31F-2	GASKET	1
48	1E33F-1	CYLINDER	1

NO.	Part NO.	Part Name	Qty.
49	GB/T70.1	SCREW M5×18	4
50	GB/T859	WASHER 5	4
51	GB/T97.1	WASHER 5	4
52	1E31F.5	GUIDE COVER ASS'Y	1
53	L6(LD)	SPARK PLUG	1
54	1E40F-3A.8-2	SPRING	1
55	1E34F.5-3	PLUG CAP	1
56	1E34F.5-2	CAP	1
57	1E40F-5.3-1	PLUG	1
58	1E36F-2-7	COVER	1
59	GB/T9074.4	SCREW M5X20	1
60	1E31F-5	GASKET	2
61	1E31F.2	MUFFLER	1
62	GB/T9074.4	SCREW M5X20	2
63	GB/T9074.4	SCREW M5X12	1
64	CG305F-14	LABEL	1
65	1E34F-14	BOLT	1
66	GB/T6187	NUT M5	2
67	1E31F-3	MUFFLER COVER	1
68	1E36F-2-2	GASKET	1
69	1E36F-2A-2	ADMITTING PIPE	1
70	1E36F-2A-1	GASKET	1
71	1E31F.1A	CARBURETOR	1
72	1E34F.1-2	CHOKER HANDLER	1
73	1E34F.1.1-1	PIPE	1
74	1E34F.1-7	STOP RING	1
75	1E34F.1.1	CLEANER INSIDE COVER	1
76	GB/T9074.4	SCREW M5X50	2
77	1E36F.1	STARTER	1
78	1E34F.1-3	CHOKER	1
79	GB/T845	SCREW ST4.2X12-F-H	1
80	1E34F.1-1	FILTER	1
81	1E34F.1-4	CLEANER OUTSIDE COVER	1
82	1E34F.1.2	SCREW	2
83	GB/T9074.4	SCREW M5X16	1
84	1E34F.9.2-3	CLEANER COVER	1
85	1E36F-2A.3.1-2	FUEL PIPE	1
86	1E36FF.8.1-1	PLUG	1
87	1E36F-2A.3.1-1	FUEL PIPE	1
88	1E31F.7-1	FUEL TANK	1
89	1E32FL.6.2-1	Fuel Tank Lid	1
90	CG420.1.3.1-2	GASKET	1
91	EB-415.4.1.1-1	Airscoop	1
92	1E32FL.6.2-2	Inside Cover	1
93	1E32FL.6.2	Lid ASS'Y	1
94	GB/T6172.1	NUT M8	2
95	GB/T93	WASHER 5	1

